

Instructions

niori.

Tel: +44 20 8149 5199
Email: sales@niori.co.uk
www.niori.co.uk

SKU:
NHB-F009-S40-BB

 **Ceiling Light**


 **LED**



WARNING

1. Always place the lamp on a flat, stable surface to avoid tipping or damage.
2. Indoor use only. Do not expose the lamp to moisture, rain, or extreme temperatures.
3. Make sure the power is switched off before assembling, cleaning, or replacing any part.
4. Connect the lamp to a power outlet that matches the rated voltage indicated on the label.
5. Keep away from children and pets to prevent electric shock or accidents.
6. Do not cover the lamp with fabric or paper while in use, as this may cause overheating or fire.
7. Only use bulbs and accessories recommended or provided by the manufacturer.
8. If you notice any unusual smell, heat, or malfunction, immediately unplug the lamp and contact your dealer.

Side view



Front view

